Wireshark OTG, **Extend your Wireshark** with extcap, iPad and Pi --TIPS and tricks of extcap and make use of Wireshark everywhere, any capture sources

Megumi Takeshita Ikeriri network service

Megumi Takeshita, packet otaku







- Founder, ikeriri network service co., ltd #sf21vus
 - Reseller of CACE technologies in 2008
 - Worked SE/IS at BayNetwork, Nortel
 - Wrote 10+ books about Wireshark
 - Instruct Wireshark to JSDF and other company
 - Reseller of packet capture / wireless tools
 - One of contributors of Wireshark

Translate Wireshark into Japanese

4	About Wireshark	?	\times	
	Wireshark Authors Folders Plugins Keyboard Shortcuts License			
	megumi			
	竹下 恵 (Megumi Takeshita) <megumi[at]ikeriri.ne.jp></megumi[at]ikeriri.ne.jp>			L.

Session Details

- Do you imagine your tablet can run Wireshark, Yes you can get Wireshark OTG. Megumi show you TIPS and tricks to use Wireshark with iPad Pro and Pi_{#sf21vus} You may not install many extcap interface that is not installed in default settings,
- It's time to make use of extcap interface such as sshdump.
- We can create our own customized extcap interface in easy way on Windows environment.
- Actual demonstration extend your Wireshark's extcap interface!!

<u>Note</u>

- Megumi uses iPad Pro, Raspberry Pi and Windows10 environment.
- Linux bash and Windows command prompt programming skills help you understand the session well.

#1 Wireshark OTGBring your Witeshark without PCWiteshark everywhere with iPad Pro



#sf21vus

We need

- An iPad or other tablet
- A Raspberry pi 4 or zero
- A USB-C to USB-C cable transferring both power and data



Burn the latest raspberry pi os using official imager application to microSD card.

- We use official raspberry pi imager to install the latest OS
- https://www.raspberrypi.org/documentation/in stallation/installing-images/README.md
- Using wired Ethernet connection to setup raspberry pi at the first
- I recommend to use Raspberry pi 4 because there are 1 RJ-45 as well as wireless lan (supports monitor mode) and many USB ports



Set raspberry pi as USB Gadget mode

- USB Gadget mode is a kind of USB OTG(On-The-Go),
- Your Pi works as USB host instead of USB devices.
- Note: Rapsberry Pi zero and 4 support gadget mode.
 I recommend to choose Pi4 because Wired LAN, many USB port and fast



Edit /boot/config.txt and /cmdLine.txt

- Set up Pi as USB Gadget mode, that supports USB-C as power and network
- Is /boot To find boot option setting file /boot/config.txt and /boot/cmdLine.txt
- At the last line of /boot/config.txt, add dtoverlay=dwc2
- /boot/cmdLine.txt is a long one line file We need to insert string after "rootwait quiet" Find "rootwait quiet" and insert string "modules-load=dwc2,g_ether"



SSH/DHCP server setting

- - #sf21vus

- We need to set up Pi4 act as SSH/DHCP server
- "touch /boot/ssh" to create blank file for ssh login
- "nano /etc/modules" to open modules file and add "libcomposite" to define USB3 device.
- Install DHCP server "apt-install isc-dhcp-server" and add "denyinterfaces usb0" Install dnsmasq with "sudo apt-get install dnsmasq" C re a te /etc/dnsmasq.d/usb and edit C re a te /etc/network/interfaces.d/usb0 and edit

/etc/dnsmsq.d/usb

interface=usb0



dhcp-option=3

leasefile-ro

/etc/network/interfaces.d/usb0

auto usb0 allow-hotplug usb0 iface usb0 inet static address 10.55.0.1 netmask 255.255.255.2



Create initialize script "/root/usb.sh" (1) https://www.hardill.me.uk/wordpress/2019/11/02/pi4-usbc-gadget/ #sf21vus #!/bin/bash cd /sys/kernel/config/usb gadget/ mkdir -p pi4 cd pi4 echo 0x1d6b > idVendor # Linux Foundationecho 0x0104 > idProduct # Multifunction Composite Gadget echo 0x0100 > bcdDevice # v1.0.0echo 0x0200 > bcdUSB # USB2echo 0xEF > bDeviceClassecho 0x02 > bDeviceSubClassecho 0x01 > bDeviceProtocolmkdir -p strings/0x409/configuration

Create initialize script "/root/usb.sh" (2) https://www.hardill.me.uk/wordpress/2019/11/02/pi4-usbc-gadget/

echo 250 > configs/c.1/MaxPower # see gadget configurations below mkdir -p functions/ecm.usb0 HOST="00:dc:c8:f7:75:14" # "HostPC" SELF="00:dd:dc:eb:6d:a1" # "BadUSB" echo \$HOST > functions/ecm.usb0/host addr echo \$SELF > functions/ecm.usb0/dev addr In -s functions/ecm.usb0 configs/c.1/ udevadm settle -t 5 || : ls /sys/class/udc > UDC ifup usb0 service dnsmasq restart

Autorun USB initial script

- We want to start up USB gadget mode, DHCP Server and #s other service every time we start up Pi4
 There are nice initial script from "Ben's Place" https://www.hardill.me.uk/wordpress/2019/11/02/pi4-usb-c-gadget/
- Make /root/usb.sh executable with chmod +x /root/usb.sh Add /root/usb.sh before exit 0
- Set this script every time we power on Pi4 so I use S01cron start script in /etc/rc3.d(CLI) and /etc/rc5.d (GUI)



"sudo halt" to power off raspberry pi, change connection from SSH via wired LAN to USBC



- "sudo halt" to power off raspberry pi
- USE a USBC-USBC cable, connect between raspberry Pi4 and iPad Pro
- Pi4 start up with USB Gadget mode and DHCP server

16:51 Mon Aug 23 Welcome to Alpine!
You can install packages with: apk add <package></package>
You may change this message by editing /etc/motd.
iPad-Pro-11:~# ssh 10.55.0.1 The authenticity of host '10.55.0.1 (10.55.0.1)' can't be established. ECDSA key fingerprint is SHA256:CnXbX7Z1o7iloHFPtdURa5KG0wU2gDH5AqZxsvor/3A. Are you sure you want to continue connecting (yes/no/[fingerprint])? yes Warning: Permanently added '10.55.0.1' (ECDSA) to the list of known hosts.

Install "ish" from AppStore and packages

- open AppStore to look for "ish" app (free)
- "Ish" is a command line shell of iPad OS
- Open "ish" app and install openssh packages
- "apk add openssh" and other packages if you need ssh pi@10.55.0.1 to login Rapsberry Pi 4 via SSH




SSH connection via USB Gadget mode install RDP server



- Connect raspberry pi via USB Gadget mode Pi uses 10.55.0.1, and iPad gets 10.55.0.2 from dhcpd ssh 10.55.0.1, and enter username and password pi/raspberry and confirm the connection via USBC
- Also recommend to install XRDP (Remote Desktop Protocol server) if there are not installed apt-get install xrdp
- Now you can use your Wireshark cli tools such as dumpcap, tshark, mergecap, editcap, capinfos etc.

Connect via Microsoft RDP client

- Install Microsoft RDP iOS client app
- Open 10.55.0.1 and login as the same as CLI





Bring your Wireshark everywhere

- Install Microsoft RDP client
- Create shortcut of 10.55.0.1 via USB-C
- Username pi
- Password raspberry
- Wireshark works at reasonable speed. (Pi4 with 8GB RAM)

Telephony Wireless Statistics View Go Capture Analyze Tools Help $X \bigcirc \mathcal{Q} \leftarrow \rightarrow \otimes \leftarrow \rightarrow \blacksquare$ 0 0 1 Apply a display filter ... <Ctrl-/> Expression... + Protocol Length Info No. Time Source Destination 4169 5.581514904 10.55.0.1 10.55.0.5 TCP 252 3389 → 52173 [P 4170 5.582249996 10.55.0.5 10.55.0.1 TCP 66 52173 → 3389 [A 4171 5.635262404 10.55.0.5 10.55.0.1 TCP 83 52173 → 3389 [P 10.55.0.1 4172 5.635415052 10.55.0.5 TCP 66 3389 → 52173 [A + Frame 1: 90 bytes on wire (720 bits), 90 bytes captured (720 bits) on interface 0 + Ethernet II, Src: 06:cf:5f:49:b3:fa (06:cf:5f:49:b3:fa), Dst: 96:2a:14:05:56:d6 (96:2a:14:05:56:d6 H. Internet Protocol Version 4, Src: 10.55.0.5, Dst: 10.55.0.1 + Transmission Control Protocol, Src Port: 52173, Dst Port: 3389, Seq: 1, Ack: 1, Len: 24 Data (24 bytes) 96 2a 14 05 56 d6 06 cf 5f 49 b3 fa 08 00 45 02 ·*··V··· I····E· 40 00 40 06 00 4c 00 26 37 0a 37 00 05 0a 37 Q. &7.7...7 00 01 cb cd 0d 3d 05 5b 5a 06 30 cd 22 27 80 18 · · · · · = · [Z · O · " ' · · 08 00 83 ee 00 00 01 01 08 0a fb b5 f2 c1 be e7 42 ea 88 18 1e 2b e8 fc 62 2d 2e bb 73 28 36 14 B + .. b - . . s (6 54 57 d4 c9 e6 59 5a 6b 27 45 TW · · · YZk 'E wireshark_usb0_20210816220229_xzYArh.pcapng Packets: 4172 · Displayed: 4172 (100.0%) Profile: Default




Change Wireshark permission settings

- We need administrative privilege to capture packet, though Raspberrian OS works as user mode.
- We need to change Wireshark permission to be able to capture packets in user mode.
- sudo dpkg-reconfigure wireshark-common"
- Choose YES to capture packets in user mode
- "sudo adduser wireshark pi" to add user pi into wireshark group
- Restart Raspberry Pi4 and login as pi again



Enjoy capturing wired and wireless network with full-featured Wireshark, tshark and so on

- Under 15 seconds, pi starts up
- Capturing wired network using Raspberry Pi4 RJ-45 port



For wireless capturing

Capturing wireless network using external WiFi adapter that supports monitor mode (unfortunately Pi internal Wireless LAN card cannot be changed into monitor mode at default setting)



- You may use KaliLinux ARM image instead of Rapsberian.
- Open ish and check wireless card "sudo iwconfig"
- Sudo airmon-ng check kill" to stop all wireless related process
- Sudo airmon-ng start wlan1" to change into monitor mode
- "iwconfig" again to check wlan1 was changed into wlan1mon (monitor mode interface)
- Choose "View>Wireless tool bar" to show wireless settings

#2 Extcap brings the external capture source

The extcap interface is a versatile plugin interface that allows external binaries to act as capture interfaces directly in Wireshark.

- It is used in scenarios, where the source of the capture is not a traditional capture model (live capture from an interface, from a pipe, from a file, etc). The typical example is connecting esoteric hardware of some kind to the main Wireshark application.and data
- Extcaps may be any binary or script within the extcap directory. Please note, that scripts need to be executable without prefacing a script interpreter before the call.

Example extcap interface: SSH remote capture



- Let's try sample extcap interface, SSH remote #sf21vus capture
- SSH remote capture is provided by SSHDump, is option component with Wireshark,

Wireshark 3.4.5 64-bit Setup Choose Components Choose which features of Wire	shark 3.4.5 64-bit you want to install.	Tools>SSH alog duri	lDump ng Wiresha	ırk
The following components are a	available for installation.			
Select components to install:	Wireshark Wireshark TShark Image: Im	Select components to install:	MMDBResolve Androiddump SSHdump UDPdump Randpktdump	^



There are default "SSH remote capture" extcap in Wireshark (you may check Tools>SSH remote capture during install process)

Double click extcap icon (left side) to edit option

🧲 Wireshark・インターフェース オプション	: SSH remote capture X	🪄 Wireshark - インターフェース	オプション: SSH remote capture X
Server Authentication Captu	ure Debug	Server Authentication	Capture Debug
Remote SSH server address	92.168.100.116	Remote interface	wlanûmon
Remote SSH server port	22	Remote capture command	dumpcap
	▲ Wireshark・インターフェース オブション: SSH remote capture		Use sudo on the remote machine
Ì	Server Authentication Capture Debug		No promiscuous mode
	Remote SSH server username kali	Remote capture filter	3:52c1:6766:1071 or host 10.0.0.207 or host fe80::3529:dc03:c11d:efb) and port 22)
	Remote SSH server password	P 🚅 Wireshark・インターフ	エース オプション: SSH remote capture
	Path to SSH private key ////		
────────────────────────────────────	SSH key passphrase	Server Authentica	tion Capture Debug
	ProxyCommand		Run in debug mode
		Use a file for debug	
	☑ キャプチャ開始時にパラメタを保存します		

- 1. Start Wireshark
- 2. Choose "SSH remote capture" interface
- 3. Click option icon

- Cisco remote capture
 Random packet generator
 SSH remote capture
 Test Extcap Interface
 UDP Listener remote capture
- Set Remote SSH server address as some Linux host this time we use Raspberry Pi IP address 10.0.0.201
- 5. Set Remote SSH port number as 22 in the Server Tab

Wireshark	<・インターフェース オノショ	12: SSH remote	capture		×
Server	Authentication	Capture	Debug		
Remote	SSH server add	lress 10.0.0).201		
Remote \$	SSH server port	22			

6. Click Authentication tab, enter Remote SSH server username (this time we use "pi")

#sf21vus

7. Enter Remote SSH server password (this time "raspberry") Note: you may fail at the first time to connect to save the host's public key as known host

	Vireshark・インターフェース オプション: SSH remote capture X
	erver Authentication Capture Debug
	emote SSH server username pi
	emote SSH server password 🔍 🗢 🗢 🗢 🗢 🗢 🗢
	ath to SSH private key ・・・・ クリア
9	SH key passphrase
	oxyCommand

- 8. Click Capture tab, enter Remote interface
 Enter Remote capture command (dumpcap -w -) #sf21vus
 (this time we use dumpcap command, output pcap
 not to file but to standard output "-w -" option
- 9. Check "Use sudo on the remote machine" Note Remote capture filter is set automatically

Wireshark	- 1 29-21-2 729	32: SSH remot	e capture	X
Server	Authentication	Capture	Debug	
Remote i	nterface	eth0		
Remote c	capture command	dumpcap -	w –	
		🗹 Use sudo	o on the remote machine	
		🗌 No prom	iscuous mode	
Remote c	capture filter	t 10.0.0.201	or host fe80::3529:dc03:c11d:efb) and port 22)	
Packets t	to capture	0		

11. You can set debug file in case of failure sf21vus check "Run in debug mode" and set path in "Use a file for debug" text box

🚄 Wireshark・インターフェース オプション: SSH remote capture	×
Server Authentication Capture Debug	Į
🗹 Run in debug mode	
Use a file for debug C:¥Users¥TakeshitaMegu	mi¥Desktop¥debug.txt
☑ キャプチャ開始時にパラメタを保存します	
デフォルトに戻す	開始 閉じる ヘルプ

シアリル(1) 備美(1) 日式(1) 弦が(4) ・ (ルシ(1)	
cmdline: C:¥Program Files¥Wireshark¥extcap¥sshdump.execaptureex fifo ¥¥.¥pipe¥wireshark_extcap_sshdump.exe_20210816093352remote-ho	ost 10.0.0.201remote-port 22
remote-password XXXXXXXXXdebugremote-sudoremote-capture-co	
file C:¥Users¥TakeshitaMegumi¥Desktop¥debug.txtremote-username pi	
remote-filter not ((host 169.254.164.117 or host fe80::1d02:3dd9:9b24	
host fe80::a8ac:e7e4:6749:fa85 or host 192.168.13.1 or host fe80::10a	
169.254.180.167 or host fe80::8002:a1a4:8f84:b4a7 or host 169.254.74.	
fe80:::4111:b7e0:7087:4ad3 or host 169.254.16.113 or host fe80:::1933:5	j2c1:6766:1071 or host
10.0.0.201 or host fe80::3529:dc03:c11d:efb) and port 22) true	
[ssh_connect] ssh_connect: libssh 0.7.3 (c) 2003-2014 Aris Adamantiac	dis, Andreas Schneider, and
libssh contributors. Distributed under the LGPL, please refer to COPY	/ING file for information about
your rights, using threading threads_noop	
[ssh_socket_connect] ssh_socket_connect: Nonblocking connection socket	
[ssh_connect] ssh_connect: Socket connecting, now waiting for the cal	Ibacks to work
[socket_callback_connected] socket_callback_connected: Socket connect	
[ssh_client_connection_callback] ssh_client_connection_callback: SSH	server banner: SSH-2.0-
OpenSSH_7.9p1 Raspbian-10+deb10u2+rpt1	
[ssh_analyze_banner] ssh_analyze_banner: Analyzing banner: SSH-2.0-0p	enSSH_7.9p1 Raspbian-
10+deb10u2+rpt1	
[ssh_analyze_banner]_ssh_analyze_banner: We_are talking to an OpenSSH	Iclient version: 7.9 (70900)
[ssh_packet_dh_reply] ssh_packet_dh_reply: Received SSH_KEXDH_REPLY	
[ssh_client_dh_reply] ssh_client_dh_reply: SSH_MSG_NEWKEYS_sent	
[ssh_packet_newkeys] ssh_packet_newkeys: Received SSH_MSG_NEWKEYS	
[ssh_packet_newkeys] ssh_packet_newkeys: Signature verified_and valid	
[ssh_userauth_publickey_auto] ssh_userauth_publickey_auto: Tried ever	
[channel_open] channel_open: Creating a channel 43 with 64000 window	and 32/68 max packet
[ssh_packet_global_request] ssh_packet_global_request: Received SSH_M	ISG_GLUBAL_REQUEST packet
[ssh]packet[global[request] ssh]packet[global[request: UNKNOWN SSH_MS	JG_GLUBAL_REQUEST hostkeys-
QO@openssh.com 0	
[ssh_packet_process] ssh_packet_process: Couldn't do anvthing with pa	
[ssh_packet_channel_open_conf] ssh_packet_channel_open_conf: Received	I A CHANNEL_UPEN_CONFIRMATION
for channel 43:0	
[ssh_packet_channel_open_conf] ssh_packet_channel_open_conf: Remote #	/indow : U, maxpacket : 32/68
Remote capture command has disabled other options	
Running; dumpcap -w -	
[channel_rcv_change_window] channel_rcv_change_window: Adding 2097152	'bytes to channel (43:U) (from

X

0 bytes) [channel_request] channel_request: Channel request exec success

[grow_window] grow_window: growing window (channel 43:0) to 1280000 bytes [grow_window] grow_window: growing window (channel 43:0) to 1280000 bytes

12. Click Start to capture packet at remote SSH host

13. You can get the trace at the Pi's side remote LAN interface

	🛿 💿 📙 🔚 🗙 💽 ۹ 🗇 🥯 警 🖗 👲 イルタ … 〈Ctrl-/〉を適用	= = 4 4 4 H			ーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーーー
lo.	Time	Source	Destination	Protocol	Length Identification Info
	1183.607382830	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1193.607390848	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1203.607398737	10.0.0.201	10.0.0.207	SSH	3780xc Server: Encrypted pac
	1213.607696735	10.0.0.207	10.0.0.201	TCP	600xc… 59758 → ssh(22) [ACK]
	1223.608096011	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1233.608106566	10.0.0.201	10.0.0.207	SSH	15…0xc… Server: Encrypted pa
	1243.608114603	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1253.608122788	10.0.0.201	10.0.0.207	SSH	15…0xc… Server: Encrypted pa
	1263.608130733	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1273.608237621	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted page
	1283.608247325	10.0.0.201	10.0.0.207	SSH	150xc Server: Encrypted pac
	1293.608255491	10.0.0.201	10.0.0.207	SSH	1220xc Server: Encrypted page
	1202 600261157	10 0 0 107	10 0 0 001	тср	(A A A A A A A A A A A A A A A A A A A

Then let's test your own extcap interface

- Extcap is useful so you can extend capture source^{f21vus}
- There are some nice hardware, such as Bluetooth dongle and open source capture devices to capture via extcap interface.
- At first, let's test your own extcap interface. Man page of extcap (<u>https://www.wireshark.org/docs/man-pages/extcap.html</u>)
- We do not need to create binary, but just a bit of batch file to test extcap interface

Check your extcap path Help>About Wireshark>Folder



- Personal Extcap Path in Windows Default C:YUsersYuserYAppDataYRoamingYWiresharkYextcap
- Global Extcap Path in Windows Default
 C:YProgram FilesYWiresharkYextcap

	(C:) > Program Files > Wireshark > extcap	ٽ ~
^	名前	更新日時
	🚄 ciscodump.exe	2021/07/15 2:29
а	🚄 randpktdump.exe	2021/07/15 2:29
	🚄 sshdump.exe	2021/07/15 2:29
	🚄 udpdump.exe	2021/07/15 2:29
	🚄 androiddump.exe	2021/07/15 2:29
	💿 nrf_sniffer_ble.bat	2021/07/12 12:54
	📄 nrf_sniffer_ble.py	2021/07/12 12:54
	📄 nrf_sniffer_ble.sh	2021/07/12 12:54
	📄 requirements.txt	2021/07/12 12:54
	📧 USBPcapCMD.exe	2020/05/22 18:01
	📙 SnifferAPI	2021/07/12 13:04
n l	🔒 extcap	2021/07/12 12:54

/ireshark 作者	フォルダ ブラグイン キーボードショートカット 確認 ライセン	ス
ペスでフィルタ		
名前	場所	典型的なファイル
'ファイル" ダイアログ	C:¥Users¥TakeshitaMegumi¥Downloads¥	キャプチャファイル
一時的	C:¥Users¥TAKESH~1¥AppData¥Local¥Temp	名称未設定キャプチャファイル
固人設定	C:¥Users¥TakeshitaMegumi¥AppData¥Roaming¥Wireshark	dfilters, preferences, ethers,
ゲローバル設定	C:¥Program Files¥Wireshark	dfilters, preferences, manuf,
システム	C:¥Program Files¥Wireshark	ethers, ipxnets
プログラム	C:¥Program Files¥Wireshark	プログラムファイル
固人プラグイン	C:¥Users¥TakeshitaMegumi¥Appoaming¥Wireshark¥plugins¥3.4	バイナリプラグイン
グローバルプラグイン	C:¥Program Files¥Wireshark¥plugins¥3.4	バイナリプラグイン
固人Luaプラグイン	C:¥Users¥TakeshitaMegumi¥Apa¥Roaming¥Wireshark¥plugins	luaスクリプト
グローバルLuaプラグイン	C:¥Program Files¥Wireshark¥plugins	luaスクリプト
固人Extcapパス	C:¥Users¥TakeshitaMegumi¥Apta¥Roaming¥Wireshark¥extcap	Extcapプラグイン検索パス
グロー/(Jl/Extcap/(ス	C:¥Program Files¥Wireshark¥extcap	Extcapプラグイン検索パス
MaxMind DB パス	C:¥ProgramData¥GeoIP	MaxMind DB データベース検索パス
MaxMind DB パス	<u>C:¥GeoIP</u>	MaxMind DB データベース検索パス
MaxMind DB パス MIB/PIB パス	<u>C:/Users/TakeshitaMegumi/AppData/Roaming/Wireshark/geoip</u>	MaxMind DB データベース検索パス SMI MIB/PIB 検索パス

Extcap man page (https://www.wireshark.org/docs/man-

elements					
arg (options)	argument for CLI calling				
number	Reference # of argument for other values, display order				
call	Literal argument to call (call=)				
display	Displayed name				
default	Default value, in proper form for type				
range	Range of valid values for UI checking (min,max) in proper form				
type	Argument type for UI filtering for raw, or UI type for selector: integer unsigned long (may include scientific / special notation) float selector (display selector table, all values as strings) boolean (display checkbox) radio (display group of radio buttons with provided values, all values as strings) fileselect (display a dialog to select a file from the filesystem, value as string) multicheck (display a textbox for selecting multiple options, values as strings) password (display a textbox with masked text) timestamp (display a calendar)				
value (options)	Values for argument selection arg Argument # this value applies to				

Create example.bat and copy into Personal Extcap Path

Example.bat




#sf71vus

echo interface {value=test}{display=Test Extcap Interface} echo dlt {number=147}{name=test}{display=Layer2 DLT} echo arg {number=1}{call=--host}{display=Filter Hostname}{type=string} {tooltip=hostname}{required=true}{default=10.0.0.201}{group=Host} echo arg {number=2}{call=--port}{display=Filter Port number} {type=unsigned}{tooltip=port}{range=1,65535}{default=22}{group=Port}

» 竹下恵 » AppData » Roaming » Wireshark » extcap					
^	名前 ^	更新日時			
	💿 example.bat	2021/08/15 14:37			

Open Wireshark and Capture>Option to check Extcap Interface



🚄 Wireshark・キャプチャオプション

「
ワイヤーシャークネットワークアナライザ

シターフェース	トラフィック	リンク層ヘッダ	プロミスキ	キャプチ
・ ローカル エリア接続* 12		Ethernet	2	デフォル
・ ローカル エリア接続* 11	_	Ethernet		デフォル
wlan	_	Ethernet		デフォル
Killer E3000 2.5 Gigabit Ethernet Controller: Ethernet		Ethernet	\checkmark	デフォル
Adapter for loopback traffic capture	٨	BSD loopback		デフォル
USBPcap1	-	USBPcap	_	_
USBPcap2	-	USBPcap	_	_
USBPcap3	-	USBPcap	_	_
Cisco remote capture	-	Remote capture dependent DLT	_	_
Random packet generator	-	Generator dependent DLT	_	_
SSH remote capture	-	Remote capture dependent DLT	_	_
Test Extcap Interface	_	Layer2 DLT	-	-
UDP Listener remote capture	-	Exported PDUs		-
] すべてのインターフェースにおいてプロミスキャスモー	ドを有効化します			
!択したインタフェースのキャプチャフィルタ: キャプ				

interface {value=test}
{display=Test Extcap Interface}


You can find your Extcap interface at Interface list in your Wireshark startup screen

dlt {number=147}{name=test}{display=Layer2 DLT}

Select Capture>Option and look the Link layer header Column to check your extcap data link type value



Click option button () to fi lo your extcap dialog(1)



echo arg {number=1}{call=--host}{display=Filter Hostname}{type=string}
{tooltip=host}{required=true}{default=10.0.0.201}{group=Host}

You can create your Extcap Option GUI using script Set number to set reference number and display order Set call to call function (this time do nothing) Set display to set the display name Set type to set the type definition (this time is string) Set tooltip to set tooltip string Set required to set this value is necessary Set default to set default value Set group to set the tab name

Click option button (\odot) to find your extcap dialog(2)



echo arg {number=2}{call=--port}{display=Filter Port number}{type=unsigned}
{tooltip=port}{range=1,65535}{default=22}{group=Port}

You can create your Extcap Option GUI using script Set number to set reference number and display order Set call to call function (this time do nothing) Set display to set the display name Set type to set type definition (this time is unsigned) Set tooltip to set tooltip string Set range to set the range of the value (this time is from 1 to 65535) Set default to set default value Set group to set the tab name

Then check SSHDump command

- Open Global Extcap Path in explorer in Windows Default C:¥Program Files¥Wireshark¥extcap
- Check sshdump.exe is in Global Extcap path
- Open command prompt and execute sshdump.exe

PC	 OS (C:) Program Files Wires 	hark > extcap >	5 V	,Ω extcapΩ
^	名前	更新日時	種類	サイズ
	🚄 ciscodump.exe	2021/07/15 2:29	アプリケーション	331 KB
	🚄 randpktdump.exe	2021/07/15 2:29	アプリケーション	326 KB
	🚄 sshdump.exe	2021/07/15 2:29	アプリケーション	324 KB
	🚄 udpdump.exe	2021/07/15 2:29	アプリケーション	320 KB
	🚄 androiddump.exe	2021/07/15 2:29	アプリケーション	349 KB
	💿 nrf_sniffer_ble.bat	2021/07/12 12:54	Windows /(ッチ ファ	1 KB
	🛃 nrf_sniffer_ble.py	2021/07/12 12:54	Python File	22 KB
	📄 nrf_sniffer_ble.sh	2021/07/12 12:54	SH ファイル	1 KB
	📄 requirements.txt	2021/07/12 12:54	テキスト ドキュメント	1 KB
	USBPcapCMD.exe	2020/05/22 18:01	アプリケーション	56 KB
	📒 SnifferAPI	2021/07/12 13:04	ファイル フォルダー	
	📒 extcap	2021/07/12 12:54	ファイル フォルダー	



There are many options for sshdump

sshdump.exe options

- --extcap-interfaces: list the extcap Interfaces
- --extcap-dlts: list the DLTs
- --extcap-interface <iface>: specify the extcap interface
- --extcap-config: list the additional configuration for an int
- --capture: run the capture
- --extcap-capture-filter <filter>: the capture filter
- --fifo <file>: dump data to file or fifo
- --extcap-version: print tool version
- --debug: print additional messages
- --debug-file: print debug messages to file
- --help: print this help
- --version: print the version
- --remote-host <host>: the remote SSH host
- --remote-port <port>: the remote SSH port
- --remote-username <username>: the remote SSH username
- --remote-password <password>: the remote SSH password. If not specified, ssh-agent and ssh-key are used

- --sshkey <public key path>: the path of the ssh key
- --sshkey-passphrase <public key passphrase>: the passphrase to unlock public ssh
- --proxycommand <proxy command>: the command to use as proxy the the ssh connection
- --remote-interface <iface>: the remote capture interface
- --remote-capture-command <capture command>: the remote capture command
- --remote-sudo: use sudo on the remote machine to capture
- --remote-noprom: don't use promiscuous mode on the remote machine
- --remote-filter <filter>: a filter for remote capture (default: don't listen on local interfaces IPs)
- --remote-count <count>: the number of packets to capture

Check debug.txt created by sshdump.exe

We make use of sshdump.exe to create our own extcap interface



#sf21vus

×

🧾 debug.txt - 义モ帳

ファイル(F) 編集(E) 君式(O) 表示(V) ヘルプ(H)

cmdline: C:¥Program Files¥Wireshark¥extcap¥sshdump.exe --capture --extcap-interface sshdump.exe -fifo ¥¥.¥pipe¥wireshark_extcap_sshdump.exe_20210816093352 --remote-host 10.0.0.201 --remote-port 22 --remote-password XXXXXXXX --debug --remote-sudo --remote-capture-command dumpcap -w - --debugfile C:¥Users¥TakeshitaMegumi¥Desktop¥debug.txt --remote-username pi --remote-interface eth0 -remote-filter not ((host 169.254.164.117 or host fe80::1d02:3dd9:9b24:a475 or host 192.168.116.1 or host fe80::a8ac:e7e4:6749:fa85 or host 192.168.13.1 or host fe80::10a:9e56:dbd6:113d or host 169.254.180.167 or host fe80::8002:a1a4:8f84:b4a7 or host 169.254.74.211 or host fe80::4111:b7e0:7087:4ad3 or host 169.254.16.113 or host fe80::1933:52c1:6766:1071 or host 10.0.0.201 or host fe80::3529:dc03:c11d:efb) and port 22) true

sshdump.exe command



"C:¥Program Files¥Wireshark¥extcap¥sshdump.exe" -capture --extcap-interface sshdump.exe --fifo %fifo% --remote-host 10.0.201 --remote-port 22 --remote-password raspberry --debug --remote-sudo --remote-capture-command "dumpcap -P -w -" --debug-file C:¥Users¥TakeshitaMegumi¥Desktop¥debug.txt --remote-username pi --remote-interface eth0 true

So let's create example2.bat file to create your own extcap interface to make use of SSHDump

example2.bat (initialization)

set "capture=0"
set "extcap_interfaces=0"
set "extcap_interface="
set "extcap_dlts=0"
set "fifo="

Initialization of command variables such as capture, extcap_interfaces, extcap_ interface, extcap_dlts, fifo

#sf21vus

Flag 0:off 1:on

example2.bat (parse) %~1 is the first parameter without quarts, %~2 is the second.
REM check command line parameters If there are no parameter, #sf21vus
if "%~1"=="" goto :main jump to the main function.
if /i "%~1"=="capture" set "capture=1" & shift & goto :parse
if /i "%~1"=="extcap-interfaces" set "extcap_interfaces=1" & shift &
goto :parse
if /i "%~1"=="extcap-interface" set "extcap_interface=%~2" & shift &
shift & goto :parse
if /i "%~1"=="fifo" set "fifo=%~2" & shift & shift & goto :parse
if /i "%~1"=="extcap-dlts" set "extcap_dlts=1" & shift & goto :parse
shift Check command line parameters, and if the parameter matches the option,
goto :parse set the flag as 1, use shift to adjust parameter and jump parse again
(shift decrease the position of the parameter and save.

example2.bat (main)

:main

exit /B

Main function check each flags and jump at corresponding labels

#sf21vus

REM – Process request for interface list from Wireshark

if "%extcap_interfaces%"=="1" call :extcap_interface_func & goto :end

REM – Process request for dlts list from Wireshark

if "%extcap_dlts%"=="1" call :extcap_dlts_func & goto :end

REM – Process capture request

if "%capture%"=="1" call :capture_func & goto :end

Check command line parameters, and if the parameter matches the option, set the flag as 1 and jump parse again

example2.bat (extcap_interface_func) :extcap_interface_func echo interface {value=test2}{display=Capture from Pi}

exit /B 0 Show extcap interface as the request for interface list from Wireshark and exit


example2.bat (extcap_dlts_func) :extcap_dlts_func

echo dlt {number=147}{name=test2}{display=Layer2 DLT}

#sf21vus

exit /B 0 Show datalink header type as the request for dlts from Wireshark and exit

example2.bat (capture_func)





#sf21vu

Let's try your customized extcap interface

- Copy example2.bat to the personal extcap path (C:¥Users¥username¥AppData¥Roaming¥Wireshark¥extcap)
- Close and open Wireshark and check your own extcap interafaces (Capture from Pi)
- 3. Double click "Capture from Pi" and get the trace





Test Extcap Interface



Capture from Pi

Let's try your customized extcap interface

💰 Capture	from Pi からキャプラ	 チャ中										_		×
 ファイル(E)	編集(E) 表示(⊻) 移動(<u>G</u>)	キャプチャ(<u>C</u>)	分析(<u>A</u>)	統計(<u>S</u>)	電話(y)	無線(<u>W</u>)	ツール(D	ヘルプ(出)					
🛋 🔳 🙇	•	69	⇔ ⇔ 🕾 1	ē 🕹 📃		ତ୍ତ୍								
■ 表示フィ	ルタ … 〈Ctrl-/	◇を適用									イのMAC	TCP.	ストリーム	を抽出
No.	Time	-			Source				Des	tination				F
	913.	. 3378	360		10.0	0.0.	201		16	0.0	.0.2	207		!
	923.	3378	370		10.0).0.	201		10	0.0	.0.2	207		!
	933.	3378	378		10.0	0.0.	201		10	0.0	.0.2	207		!
L	943.	3380	965		10.0	0.0.	207		10	0.0	.0.2	201		-
۲														>
> Fra	me 1:	134	byte	es c	n w	ire	(10	972	bit	s),	134	4 b	ytes	5 ([°]
› Eth	ernet	II,	Src	: Ra	ispb	err	_1e:	:3a:	a0	(e4	:5f	:01	:1e:	:3;
> Int	ernet	Pro	toco	l Ve	ersi	on	4, 9	Src:	10	.0.	0.20	91	(10)	.0
2 Tra	ncmic	cion	Cont	rol	Dr	<u></u>	<u></u>	٢r	C D	nt	• •	ch	(<u>ب</u>
,000	0 rr	<u>18</u>	Ra 5d	R	dΔ	ρĄ	5f	Ø 1	1e	٦a	۶Й	٨Ŋ	99	٦ ٢
○ ℤ c	apture from Pi	i: <live cap<="" td=""><td>ture in prog</td><td>ress></td><td></td><td></td><td></td><td>パケット数</td><td>な:94・表:</td><td>क्तः 94 (1</td><td>00.0%)</td><td>רכםל </td><td>ィル: Def</td><td>fault</td></live>	ture in prog	ress>				パケット数	な:94・表:	क्तः 94 (1	00.0%)	רכםל	ィル: Def	fault


 Just a double click of your own extcap interface, you can get traces from remote host using Wireshark

#sf21vus

Reference : Windows 10 Wireshark Plug-in for WLANPi Wireless Captures (wlan-extcap-win)



- Instead of batch file programing, You may also use nice batch file, ##amextcap-win by wifinigel https://github.com/wifinigel/wlan-extcap-win
- It is nice batch file script based on Adrian Granados' original python scripts on the wlan-extcap project (macOS)
- We can use Raspberry Pi's monitor mode Wi-Fi interface as one of extcap interfaces to make use of SSHDump





Download wlanpidump.bat and save to Extcap path



- Download batch file "wlanpidump.bat" and save to personal Extcap_{21vus} path (C:¥Users¥user¥AppData¥Roaming¥Wireshark¥extcap)
- Edit wlanpidump.bat and find "set capture_cmd" section

set capture_cmd="%kill_old_instances_cmd% %time_cmd% %if_down% %set_moni tor% %if_up% sudo /usr/sbin/iw %remote_interface% **set** channel %remote_channel% % remote_channel_width% > /dev/null && /usr/sbin/tcpdump -i %remote_interface% %f ilter_statement% -s %frame_slice% -U -w - "↓

call "%sshdump_path%" --extcap-interface sshdump --remote-host %host% -remote-port %port% --remote-capture-command %capture_cmd% --remote-username %use rname% --remote-password %password% --fifo %fifo% --capture↓

The batch file create GUI of wireless settings, set parameters, set wireless interface as monitor mode, create capture command and call SSHDump to capture wireless packet via ssh connection from Raspberry Pi

Use wlan-extcap-win extcap interface

- 1. Close and open Wireshark again
- 2. You can find WLAN Pi extcap interfa
- 3. Click Option icon 🕥

- 🕽 🛛 Random packet generator
- SSH remote capture
- Test Extcap Interface
- UDP Listener remote capture
- WLAN Pi 1.x rem cap (Win) (v0.04)
- Choose Channel and Channel Width in Capture TAB (this time we use Channel 1 and 20MHz bandwidth)

🚄 Wireshark - インターフェース オプション: WLAN Pi 1.x rem cap (Win) (v0.04)							
Capture Server Authentication Adv	vanced						
Channel	Channel 1 / 2412 MHz 🗸 🗸						
Channel Width	Channel 1 / 2412 MHz Channel 2 / 2417 MHz Channel 3 / 2422 MHz Channel 4 / 2427 MHz Channel 5 / 2432 MHz Channel 5 / 2432 MHz Channel 6 / 2437 MHz Channel 7 / 2442 MHz Channel 8 / 2447 MHz						
☑ キャプチャ開始時にパラメタを保存します デフォルトに戻す	Channel 9 / 2452 MHz Channel 10 / 2457 MHz 開始 閉じる ヘルプ						

Use wlan-extcap-win extcap interface

- Set Remote host IP address and Port in WLAN Pi Address and WLAN Pi Port fields in Server tab (used for SSHDump parameter)
- 6. Set Remote host username and password in Authentication tab

		_			
🚄 Wireshark・インターフェース オプション: WLAN Pi 1.x rem cap (Win) (v0.04)	🧹 Wireshark - インターフェース オプション: WLAN Pi 1.x rem cap (Win) (v0.04)				
CaptureServerAuthenticationAdvancedWLAN Pi Address10.0.0.201WLAN Pi Port22	Capture Server Authentication Advanced WLAN Pi Username pi WLAN Pi Password raspberry Path to SSH Private Key … クリア				

Use wlan-extcap-win extcap interface

- Set remote interface, capture filter (option), 7. #sf21vus Frame Slice, and Sync WLANPi Time option in advanced tap (we use wlan1 as remote interface, no capture filter, capture all frames using 0 as Frame Slice and disabled Sync WLANPi Time)
- 8. Click Start to capture wireless packet via Raspberry Pi

🧲 Wireshark・インターフェース:	オプション: WLAN Pi 1.x rem cap (Win) (v0.04)	×				
Capture Server	Authentication Advanced					
Remote Interface wlan1						
Remote Capture Filter						
Frame Slice (bytes)	0					
Sync WLANPi Time	O Disabled					
	⊖ Enabled					


USE WIRESHARK Thank you for watching !!

Please complete the SharkFest Europe app-based survey



Supplemental file

http://www.ikeriri.ne.jp/sharkfest



ikeriri network service
http://www.ikeriri.ne.jp